

SLAPSTICK Installation Instructions



Clean the surface you're applying SlapStick to. Make sure it's free of dust, dirt, chalk, etc. The surface must be completely dry before applying.



Turn over the panel and peel back about 6" of liner. Line up the panel to one side of board.



One person slowly smooths the board going up and down, side to side with the magnetic eraser included in your kit. This process reduces air bubbles forming during installation. The other person stands behind the panel pulling the liner as it's smoothed into place. If need be, the panel can be lifted off the board and reapplied.



If there are multiple parts, align the second panel along the edge of the installed panel. Repeat application.



If the SlapStick overlaps the board, use a straight edge to score the board and trim with a utility knife.



Wipe off board with enclosed cleaner in the SlapStickKit. Enjoy!



view the installation video at romoslapstick.com