Applying Pressure Sensitive Decals

By following these basic instructions, you'll save time and energy during the application.

Keep in mind our graphics are permanen and not repositionable.

Please read through the instructions carefully before applying.

ROMO DURABLE-GRAPHICS

Prep the Surface

Sand, clean and dry.

- Using the provided sandpaper, remove any loose ink.
- Wipe debris from the surface and wash the surface with soap & water or Isopropyl Alcohol and a lint-free cloth.
- Both the lid and the decal should be at or near room temperature.

Place the Graphic

Set the graphic in place.

- You can hold it in place by using masking tape across the top.
- Flip the label over and peel back at the slit in the middle.
- Peel the liner off the backside one side of of the decal slowly from the middle to the edge.

Secure the Deca

Apply pressure to secure adhesive.

- Evenly, across the entire graphic and edges, apply pressure using your hand or squeegee as you remove the liner.
- Repeat the process on the other half of the decal.
- The new decal is slightly larger than the current graphic to cover the area completely.